



PARAGON

DRAIN KIT

This kit includes (2) male fittings and (2) female fittings

Garment

1. Connect female fittings to the male fittings on the garment.
2. Set air compressor to a maximum of 40-50 psi. Insert air compressor hose, with a small nozzle attachment, into the tubing attached to the female connector. Cycle air compressor for a maximum of 10-15 seconds.

Water Hose

1. Connect female fittings to the male fittings on the hose and connect male fittings to the female fittings on the hose.
2. Set air compressor to a maximum of 40-50 psi. Insert air compressor hose, with a small nozzle attachment, into the tubing attached to the female connector. Cycle air compressor for a maximum of 10-15 seconds.



PARAGON

DRAIN KIT

This kit includes (2) male fittings and (2) female fittings

Garment

1. Connect female fittings to the male fittings on the garment.
2. Set air compressor to a maximum of 40-50 psi. Insert air compressor hose, with a small nozzle attachment, into the tubing attached to the female connector. Cycle air compressor for a maximum of 10-15 seconds.

Water Hose

1. Connect female fittings to the male fittings on the hose and connect male fittings to the female fittings on the hose.
2. Set air compressor to a maximum of 40-50 psi. Insert air compressor hose, with a small nozzle attachment, into the tubing attached to the female connector. Cycle air compressor for a maximum of 10-15 seconds.